



EC200N-CN&EC800M-CN

GNSS Application Note

LTE Standard Module Series

Version: 1.0.0

Date: 2023-02-07

Status: Preliminary



At Quectel, our aim is to provide timely and comprehensive services to our customers. If you require any assistance, please contact our headquarters:

Quectel Wireless Solutions Co., Ltd.

Building 5, Shanghai Business Park Phase III (Area B), No.1016 Tianlin Road, Minhang District, Shanghai 200233, China

Tel: +86 21 5108 6236

Email: info@quectel.com

Or our local offices. For more information, please visit:

<http://www.quectel.com/support/sales.htm>.

For technical support, or to report documentation errors, please visit:

<http://www.quectel.com/support/technical.htm>.

Or email us at: support@quectel.com.

Legal Notices

We offer information as a service to you. The provided information is based on your requirements and we make every effort to ensure its quality. You agree that you are responsible for using independent analysis and evaluation in designing intended products, and we provide reference designs for illustrative purposes only. Before using any hardware, software or service guided by this document, please read this notice carefully. Even though we employ commercially reasonable efforts to provide the best possible experience, you hereby acknowledge and agree that this document and related services hereunder are provided to you on an "as available" basis. We may revise or restate this document from time to time at our sole discretion without any prior notice to you.

Use and Disclosure Restrictions

License Agreements

Documents and information provided by us shall be kept confidential, unless specific permission is granted. They shall not be accessed or used for any purpose except as expressly provided herein.

Copyright

Our and third-party products hereunder may contain copyrighted material. Such copyrighted material shall not be copied, reproduced, distributed, merged, published, translated, or modified without prior written consent. We and the third party have exclusive rights over copyrighted material. No license shall be granted or conveyed under any patents, copyrights, trademarks, or service mark rights. To avoid ambiguities, purchasing in any form cannot be deemed as granting a license other than the normal non-exclusive, royalty-free license to use the material. We reserve the right to take legal action for noncompliance with abovementioned requirements, unauthorized use, or other illegal or malicious use of the material.

Trademarks

Except as otherwise set forth herein, nothing in this document shall be construed as conferring any rights to use any trademark, trade name or name, abbreviation, or counterfeit product thereof owned by Quectel or any third party in advertising, publicity, or other aspects.

Third-Party Rights

This document may refer to hardware, software and/or documentation owned by one or more third parties ("third-party materials"). Use of such third-party materials shall be governed by all restrictions and obligations applicable thereto.

We make no warranty or representation, either express or implied, regarding the third-party materials, including but not limited to any implied or statutory, warranties of merchantability or fitness for a particular purpose, quiet enjoyment, system integration, information accuracy, and non-infringement of any third-party intellectual property rights with regard to the licensed technology or use thereof. Nothing herein constitutes a representation or warranty by us to either develop, enhance, modify, distribute, market, sell, offer for sale, or otherwise maintain production of any our products or any other hardware, software, device, tool, information, or product. We moreover disclaim any and all warranties arising from the course of dealing or usage of trade.

Privacy Policy

To implement module functionality, certain device data are uploaded to Quectel's or third-party's servers, including carriers, chipset suppliers or customer-designated servers. Quectel, strictly abiding by the relevant laws and regulations, shall retain, use, disclose or otherwise process relevant data for the purpose of performing the service only or as permitted by applicable laws. Before data interaction with third parties, please be informed of their privacy and data security policy.

Disclaimer

- a) We acknowledge no liability for any injury or damage arising from the reliance upon the information.
- b) We shall bear no liability resulting from any inaccuracies or omissions, or from the use of the information contained herein.
- c) While we have made every effort to ensure that the functions and features under development are free from errors, it is possible that they could contain errors, inaccuracies, and omissions. Unless otherwise provided by valid agreement, we make no warranties of any kind, either implied or express, and exclude all liability for any loss or damage suffered in connection with the use of features and functions under development, to the maximum extent permitted by law, regardless of whether such loss or damage may have been foreseeable.
- d) We are not responsible for the accessibility, safety, accuracy, availability, legality, or completeness of information, advertising, commercial offers, products, services, and materials on third-party websites and third-party resources.

Copyright © Quectel Wireless Solutions Co., Ltd. 2023. All rights reserved.

About the Document

Revision History

Version	Date	Author	Description
-	2022-02-26	Yang LIU/ Evin ZHU/ Felix LIU	Creation of the document
1.0.0	2023-02-07	Yang LIU/ Evin ZHU/ Felix LIU	Preliminary

Contents

About the Document	3
Contents	4
Table Index.....	5
1 Introduction	6
1.1. GNSS Turning On/Off Procedures	6
1.2. Supported NMEA Sentence Types.....	6
2 Description of GNSS AT Commands.....	8
2.1. AT Command Introduction	8
2.1.1. Definitions.....	8
2.1.2. AT Command Syntax	8
2.2. Declaration of AT Command Examples	9
2.3. AT Commands Description	9
2.3.1. AT+QGPSCFG Configure GNSS.....	9
2.3.1.1. AT+QGPSCFG="outport" Configure Output Port of NMEA Sentences.....	9
2.3.1.2. AT+QGPSCFG="nmeasrc" Enable/Disable Acquisition of NMEA Sentences Through AT+QGPSGNMEA.....	10
2.3.1.3. AT+QGPSCFG="gpsnmeatype" Configure Output Type of NMEA Sentences	11
2.3.1.4. AT+QGPSCFG="gnssconfig" Configure Enabled GNSS Constellations	12
2.3.1.5. AT+QGPSCFG="autogps" Enable/Disable GNSS to Run Automatically	13
2.3.1.6. AT+QGPSCFG="apflash" Enable/Disable AP-Flash Quick Hot Start Solution	14
2.3.2. AT+QGPSDEL Delete Assistance Data.....	15
2.3.3. AT+QGPS Turn on GNSS.....	16
2.3.4. AT+QGPSEND Turn off GNSS	16
2.3.5. AT+QGPSLOC Acquire Positioning Information.....	17
2.3.6. AT+QGPSGNMEA Acquire Specified NMEA Sentences	19
2.3.7. AT+QAGPS Enable/Disable AGPS.....	21
3 Example	23
3.1. Turn on NMEA Port to Output.....	23
3.2. Turn on/off GNSS.....	25
3.3. Application of <NMEA_src>	26
3.4. Application of AGPS Feature	26
4 Summary of Error Codes	27
5 Appendix References	28

Table Index

Table 1: Types of AT Commands	8
Table 2: Summary of Error Codes	27
Table 3: Terms and Abbreviations	28

1 Introduction

Quectel EC200N-CN and EC800M-CN modules integrate the multi-GNSS engine which supports GPS, BeiDou, Galileo and GLONASS systems. The high-performance GNSS engine is suitable for various application scenarios with low cost and accurate positioning requirements, and supports location tracking without any network assistance. This makes the following applicable modules widely used in fields such as turn-by-turn navigation, asset tracking, personnel tracking, location-aware games, as well as home and fleet management.

1.1. GNSS Turning On/Off Procedures

The GNSS of EC200N-CN and EC800M-CN modules support location calculation without any network assistance. GNSS turning on/off procedures are shown below:

Step 1: Configure GNSS parameters through **AT+QGPSCFG**.

Step 2: Turn on GNSS through **AT+QGPS=1**.

Step 3: Obtain the positioning information in any of the following three ways after turning on GNSS and fixing position successfully:

- (1) NMEA sentences are not output by default. You can select the output port of NMEA sentences through **AT+QGPSCFG="outport"**.
- (2) Obtain positioning information such as latitude, longitude, height, GNSS positioning mode, time, number of satellites directly through **AT+QGPSLOC**.
- (3) Set **AT+QGPSCFG="nmeasrc",1** to enable acquisition of specified NMEA sentences through **AT+QGPSGNMEA**, the specified NMEA sentences cannot be acquired through **AT+QGPSGNMEA** if **AT+QGPSCFG="nmeasrc",0** is set.

Step 4: Turn off GNSS through **AT+QGPS=0** or **AT+QGPSEND**.

1.2. Supported NMEA Sentence Types

The default NMEA sentences of the modules are compatible with NMEA 0183 protocol, and three kinds of prefixes are available to differentiate NMEA sentences of different satellite systems, as illustrated below.

GPS NMEA sentences have the prefix “GP”:

- GPGGA – Global positioning system fix data, such as time, position
- GPRMC – Recommended minimum specific GNSS data
- GPGSV – GPS satellites in view, such as number of satellites in view, satellite ID numbers
- GPGSA – GNSS DOP and active satellites
- GPVTG – Course over ground and ground speed
- GPGLL – Longitude and latitude

BeiDou NMEA sentences have the prefixes “GB”:

- GBGGA – Global positioning system fix data, such as time, position
- GBRMC – Recommended minimum specific GNSS data
- GBGSV – BeiDou satellites in view, such as number of satellites in view and satellite ID numbers
- GBGSA – BeiDou DOP and active satellites
- GBVTG – Course over ground and ground speed
- GBGLL – Longitude and latitude

Galileo NMEA sentences have the prefixes “GA”:

- GAGGA – Global positioning system fix data, such as time, position
- GARMC – Recommended minimum specific GNSS data
- GAGSV – Galileo satellites in view, such as number of satellites in view and satellite ID numbers
- GAGSA – Galileo DOP and active satellites

GLONASS NMEA sentences have the prefixes “GL”:

- GLGGA – Global positioning system fix data, such as time, position
- GLRMC – Recommended minimum specific GNSS data
- GLGSV – GLONASS satellites in view, such as number of satellites in view and satellite ID numbers
- GLGSA – GLONASS DOP and active satellites

GNSS Multi-constellations NMEA sentences have the prefix “GN”:

- GNGGA – Global positioning system fix data, such as time, position
- GNRMC – Recommended minimum specific GNSS data
- GNGSA – GNSS DOP and active satellites
- GNVTG – Course over ground and ground speed
- GNGLL – Longitude and latitude

NOTE

EC200N-CN module does not support GLONASS and Galileo systems currently.

2 Description of GNSS AT Commands

2.1. AT Command Introduction

2.1.1. Definitions

- <CR> Carriage return character.
- <LF> Line feed character.
- <...> Parameter name. Angle brackets do not appear on the command line.
- [...] Optional parameter of a command or an optional part of TA information response. Square brackets do not appear on the command line. When an optional parameter is not given in a command, the new value equals its previous value or the default settings, unless otherwise specified.
- Underline Default setting of a parameter.

2.1.2. AT Command Syntax

All command lines must start with **AT** or **at** and end with <CR>. Information responses and result codes always start and end with a carriage return character and a line feed character: <CR><LF><response><CR><LF>. In tables presenting commands and responses throughout this document, only the commands and responses are presented, and <CR> and <LF> are deliberately omitted.

Table 1: Types of AT Commands

Command Type	Syntax	Description
Test Command	AT+<cmd>=?	Test the existence of the corresponding command and return information about the type, value, or range of its parameter.
Read Command	AT+<cmd>?	Check the current parameter value of the corresponding command.
Write Command	AT+<cmd>=<p1>[,<p2>[,<p3> [...]]]	Set user-definable parameter value.
Execution Command	AT+<cmd>	Return a specific information parameter or perform a specific action.

2.2. Declaration of AT Command Examples

The AT command examples in this document are provided to help you learn about the use of the AT commands introduced herein. The examples, however, should not be taken as Quectel's recommendations or suggestions about how to design a program flow or what status to set the module into. Sometimes multiple examples may be provided for one AT command. However, this does not mean that there is a correlation among these examples, or that they should be executed in a given sequence.

2.3. AT Commands Description

2.3.1. AT+QGPSCFG Configure GNSS

This command queries and configures various GNSS settings, including the output port and output types of NMEA sentences.

AT+QGPSCFG Configure GNSS

Test Command

AT+QGPSCFG=?

Response

+QGPSCFG: "outport",(list of supported <out_port>s)
+QGPSCFG: "nmeasrc",(list of supported <NMEA_src>s)
+QGPSCFG: "gpsnmeatype",(range of supported <GPS_NME_A_type>s)
+QGPSCFG: "gnssconfig",(list of supported <GNSS_config>s)
+QGPSCFG: "autogps",(list of supported <autoGPS>s)
+QGPSCDF: "apflash",(list of supported <AP_flash_mode>s)

OK

2.3.1.1. AT+QGPSCFG="outport" Configure Output Port of NMEA Sentences

This command configures the output port of NMEA sentences.

AT+QGPSCFG="outport" Configure Output Port of NMEA Sentences

Write Command

AT+QGPSCFG="outport"[,<out_port>]

Response

If the optional parameter is omitted, query the current setting:
+QGPSCFG: "outport",<out_port>

OK

If the optional parameter is specified, configure the output

	<p>port of NMEA sentences: OK Or ERROR</p> <p>If there is any error related to ME functionality: +CME ERROR: <errcode></p>
Maximum Response Time	300 ms
Characteristics	<p>The command takes effect immediately. The configuration is saved to NVRAM automatically.</p>

Parameter

<out_port>	String type. Configure the output port of NMEA sentences. "none" Close NMEA sentence output <u>"usbnmea"</u> Output through USB NMEA port "uartdebug" Output through Debug UART port
<errcode>	Error codes. See Chapter 4 for details.

NOTE

NMEA sentences are output through USB NMEA port by default when USB NMEA port is turned on. If USB NMEA port is not turned on, NMEA sentences will not be output. If NMEA sentences need to be output through Debug UART port3.1, you need to configure it manually through **AT+QGPSCFG="outport", <out_port>**.

2.3.1.2. AT+QGPSCFG="nmeasrc" Enable/Disable Acquisition of NMEA Sentences Through AT+QGPSGNMEA

This command enables or disables acquisition of NMEA sentences through **AT+QGPSGNMEA**.

AT+QGPSCFG="nmeasrc" Enable/Disable Acquisition of NMEA Sentences Through AT+QGPSGNMEA

Write Command

AT+QGPSCFG="nmeasrc"[,<NMEA_src>]

Response

If the optional parameter is omitted, query the current setting:
+QGPSCFG: "nmeasrc",<NMEA_src>

OK

If the optional parameter is specified, configure whether to

	<p>enable acquisition of NMEA sentences through AT+QGPSGNMEA:</p> <p>OK</p> <p>Or</p> <p>ERROR</p> <p>If there is any error related to ME functionality: +CME ERROR: <errcode></p>
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is saved automatically.

Parameter

<NMEA_src>	<p>Integer type. Enable or disable the acquisition of NMEA sentences through AT+QGPSGNMEA. If enabled, after AT+QGPSGNMEA is executed, NMEA sentences are output through the AT port as a return value.</p> <p>0 Disable 1 Enable</p>
<errcode>	Error codes. See Chapter 4 for details.

2.3.1.3. AT+QGPSCFG="gpsnmeatype" Configure Output Type of NMEA Sentences

This command configures the output type of GPS, BeiDou, Galileo, GLONASS or GNSS multi-constellations NMEA sentences.

AT+QGPSCFG="gpsnmeatype" Configure Output Type of NMEA Sentences

Write Command AT+QGPSCFG="gpsnmeatype"[,<GPS_NMEA_type>]	<p>Response</p> <p>If the optional parameter is omitted, query the current setting: +QGPSCFG: "gpsnmeatype",<GPS_NMEA_type></p> <p>OK</p> <p>If the optional parameter is specified, configure the output type of GPS, BeiDou, Galileo, GLONASS or GNSS multi-constellations NMEA sentences:</p> <p>OK</p> <p>Or</p> <p>ERROR</p> <p>If there is any error related to ME functionality:</p>
--	---

	+CME ERROR: <errcode>
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is saved to NVRAM automatically.

Parameter

<GPS_NMEA_type>	Integer type. Configure output type of NMEA sentences by XOR operation. Range: 0–63. Default value: 31. 0 Disable 1 GGA 2 RMC 4 GSV 8 GSA 16 VTG 32 GLL 63 All the five types of sentences
<errcode>	Error codes. See Chapter 4 for details.

NOTE

This command can be executed to configure the output type of NMEA sentences even if GNSS is turned off. And the configuration takes effect after the module is rebooted.

2.3.1.4. AT+QGPSCFG="gnssconfig" Configure Enabled GNSS Constellations

This command configures the enabled GNSS constellations of the module.

AT+QGPSCFG="gnssconfig" Configure Enabled GNSS Constellations

Write Command

AT+QGPSCFG="gnssconfig"[,<GNSS_config>]

Response

If the optional parameter is omitted, query the current setting:
+QGPSCFG: "gnssconfig",<GNSS_config>

OK

If the optional parameter is specified, configure the enabled GNSS constellations:

OK

Or

ERROR

	If there is any error related to ME functionality: +CME ERROR: <errcode>
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is saved automatically.

Parameter

<GNSS_config>	Integer type. Configure enabled GNSS constellations. EC200N-CN module only supports the following configuration. If <GNSS_config> is set to other values, the command does not take effect. 0 GPS 5 GPS + BeiDou 7 BeiDou
	EC800M-CN series module: 0 GPS 1 GPS + BeiDou 3 GPS + GLONASS + Galileo 4 GPS + GLONASS 5 GPS + BeiDou + Galileo 6 GPS + Galileo 7 BeiDou
<errcode>	Error codes. See Chapter 4 for details.

NOTE

When GNSS is not turned on and the relevant configuration has never been made, the configuration information read by this command is 0, which is of no significance.

2.3.1.5. AT+QGPSCFG="autogps" Enable/Disable GNSS to Run Automatically

This command enables/disables the automatic running of GNSS after the module is powered on.

AT+QGPSCFG="autogps" Enable/Disable GNSS to Run Automatically

Write Command

AT+QGPSCFG="autogps"[,<autoGPS>]

Response

If the optional parameter is omitted, query the current setting:
+QGPSCFG: "autogps",<autoGPS>

OK

	If the optional parameter is specified, enable or disable the automatic running of GNSS: OK Or ERROR
Maximum Response Time	300 ms
Characteristics	The command takes effect after the module is rebooted. The configuration is saved automatically.

Parameter

<autoGPS>	Integer type. Enable/disable GNSS to run automatically. 0 Disable 1 Enable
<errcode>	Error codes. See Chapter 4 for details.

2.3.1.6. AT+QGPSCFG="apflash" Enable/Disable AP-Flash Quick Hot Start Solution

This command enables or disables the solution of AP-Flash quick hot start. After GNSS is turned on, the positioning time can be accelerated by importing ephemeris data into GNSS module.

AT+QGPSCFG="apflash" Enable/Disable AP-Flash Quick Hot Start Solution

Write Command AT+QGPSCFG="apflash"[,<AP_flash_mode>]	Response If the optional parameter is omitted, query the current setting: +QGPSCFG: "apflash",<AP_flash_mode>
	OK If the optional parameter is specified, enable or disable the solution of AP-Flash quick hot start: OK Or ERROR If there is any error related to ME functionality: +CME ERROR: <errcode>

Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is saved automatically.

Parameter

<AP_flash_mode>	Integer type. Enable or disable the solution of AP-Flash quick hot start. 0 Disable 1 Enable
<errcode>	Error codes. See Chapter 4 for details.

2.3.2. AT+QGPSDEL Delete Assistance Data

The command deletes assistance data so as to perform cold start, hot start and warm start of GNSS. The command can only be executed when GNSS is turned on.

AT+QGPSDEL Delete Assistance Data	
Test Command AT+QGPSDEL=?	Response +QGPSDEL: (range of supported <delete_type>s) OK
Write Command AT+QGPSDEL=<delete_type>	Response OK Or ERROR If there is any error related to ME functionality: +CME ERROR: <errcode>
Maximum Response Time	300 ms
Characteristics	/

Parameter

<delete_type>	Integer type. The type of GNSS assistance data to be deleted. 0 Delete all assistance data. Enforce cold start after starting GNSS 1 Do not delete any data. Perform hot start if the conditions are satisfied after starting GNSS 2 Delete some related data. Perform warm start if the conditions are satisfied after starting GNSS
<errcode>	Error codes. See Chapter 4 for details.

2.3.3. AT+QGPS Turn on GNSS

This command turns on GNSS function.

AT+QGPS Turn on GNSS

Test Command AT+QGPS=?	Response +QGPS: (list of supported <GNSS_state>s) OK
Read Comamnd AT+QGPS?	Response +QGPS: <GNSS_state> OK
Write Command AT+QGPS=<GNSS_state>	Response OK Or ERROR If there is any error related to ME functionality: +CME ERROR: <errcode>
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is not saved.

Parameter

<GNSS_state>	Integer type. Turn on or off GNSS. 0 Turn off GNSS 1 Turn on GNSS
<errcode>	Error codes. See Chapter 4 for details.

2.3.4. AT+QGPSEND Turn off GNSS

This command takes off GNSS function.

AT+QGPSEND Turn off GNSS

Test Command AT+QGPSEND=?	Response OK Or ERROR
-------------------------------------	---

Read Command AT+QGPSEND?	Response OK Or ERROR
Execution Command AT+QGPSEND	Response OK Or ERROR
	If there is any error related to ME functionality: +CME ERROR: <errcode>
Maximum Response Time	300 ms
Characteristics	/

Parameter

<errcode> Error codes. See *Chapter 4* for details.

2.3.5. AT+QGPSLOC Acquire Positioning Information

This command acquires positioning information. Before executing this command, GNSS should be turned on through **AT+QGPS**. If GNSS fails in position fix, **+CME ERROR: <errcode>** is returned to indicate the corresponding situation.

AT+QGPSLOC Acquire Positioning Information

Test Command AT+QGPSLOC=?	Response +QGPSLOC: <UTC>,<latitude>,<longitude>,<HDOP>,<altitude>,(range of supported <fix>s),<COG>,<spkm>,<spkn>,<date>,<nSAT> OK
Write Command AT+QGPSLOC=<mode>	Response +QGPSLOC: <UTC>,<latitude>,<longitude>,<HDOP>,<altitude>,<fix>,<COG>,<spkm>,<spkn>,<date>,<nSAT> OK
	If there is any error related to ME functionality: +CME ERROR: <errcode>
Maximum Response Time	300 ms

Characteristics

/

Parameter

<mode>	Integer type. Latitude and longitude display format.
0	<latitude>,<longitude> format: ddmm.mmmmN/S,dddmm.mmmmE/W
1	<latitude>,<longitude> format: ddmm.mmmmmmN/S,dddmm.mmmmmmmE/W
2	<latitude>,<longitude> format: (-)dd.ddddd,(-)ddd.ddddd
<UTC>	String type. UTC time. Format: hhmmss.ss (Quoted from GNRMC sentence).
<latitude>	String type. Latitude. If <mode> is 0: Format: ddmm.mmmmN/S (Quoted from GNRMC sentence). dd Degree. Range: 00–89 mm.mmmm Minute. Range: 00.0000–59.9999 N/S North latitude/South latitude
	If <mode> is 1: Format: ddmm.mmmmmmN/S. dd Degree. Range: 00–89 mm.mmmmmm Minute. Range: 00.000000–59.999999 N/S North latitude/South latitude
	If <mode> is 2: Format: (-)dd.ddddd. dd.ddddd Degree. Range: -89.99999 to 89.99999 - South latitude
<longitude>	String type. Longitude. If <mode> is 0: Format: dddmm.mmmmE/W (Quoted from GNRMC sentence). ddd Degree. Range: 000–179 mm.mmmm Minute. Range: 00.0000–59.9999 E/W East longitude/West longitude
	If <mode> is 1: Format: dddmm.mmmmmmmE/W (Quoted from GNRMC sentence). ddd Degree. Range: 000–179 mm.mmmmmmm Minute. Range: 00.000000–59.999999 E/W East longitude/West longitude
	If <mode> is 2: Format: (-)ddd.ddddd (Quoted from GNRMC sentence). ddd.ddddd Degree. Range: -179.99999 to 179.99999 - West longitude

<HDOP>	Horizontal dilution of precision.
<altitude>	The altitude of the antenna away from the sea level. Unit: meter (Quoted from GNGGA sentence).
<fix>	Integer type. GNSS positioning mode (Quoted from GPGSA sentence). 1 No positioning 2 2D positioning 3 3D positioning
<COG>	String type. Course Over Ground based on true north. The output is null if the speed measurement fails or the speed in static scene is extremely low (Quoted from GNRMC sentence).
<spkm>	Speed over ground. Accurate to one decimal place. Unit: km/h (Quoted from GNRMC sentence).
<spkn>	Speed over ground. Accurate to one decimal place. Unit: knots (Quoted from GNRMC sentence).
<date>	UTC date. Format: ddmmyy (Quoted from GNRMC sentence). dd Day mm Month yy Year
<nSAT>	Number of satellites in view. The value should be kept two digits, and add 0 If the leading digit is insufficient (Quoted from GNGGA sentence).
<errcode>	Error codes. See Chapter 4 for details.

2.3.6. AT+QGPSGNMEA Acquire Specified NMEA Sentences

This command acquires specified NMEA sentences. Before using this command, turn on GNSS through **AT+QGPS**, and set **<NMEA_src>** to 1 to enable acquisition of NMEA sentences through **AT+QGPSGNMEA**.

The sentence output can be disabled through **AT+QGPSCFG="gpsnmeatype",0**. If sentence output is disabled, the updated sentence is no longer output, and the NMEA sentence acquired before the sentence output is disabled after the GNSS is activated is saved. If the saved NMEA sentence contains the sentence type specified by **AT+QGPSGNMEA**, the specified NMEA sentence can still be acquired through **AT+QGPSGNMEA**.

AT+QGPSGNMEA Acquire Specified NMEA Sentences

Test Command AT+QGPSGNMEA=?	Response +QGPSGNMEA: (list of supported <NMEA_type>s) OK
Write Command Query GGA sentence AT+QGPSGNMEA="GGA"	Response [+QGPSGNMEA: <GGA_sentence>] [...]

	OK
	If there is any error related to ME functionality: +CME ERROR: <errcode>
Write Command Query RMC sentence AT+QGPSGNMEA="RMC"	Response [+QGPSGNMEA: <RMC_sentence>] [...]
	OK
	If there is any error related to ME functionality: +CME ERROR: <errcode>
Write Command Query GSV sentence AT+QGPSGNMEA="GSV"	Response [+QGPSGNMEA: <GSV_sentence>] [...]
	OK
	If there is any error related to ME functionality: +CME ERROR: <errcode>
Write Command Query GSA sentence AT+QGPSGNMEA="GSA"	Response [+QGPSGNMEA: <GSA_sentence>] [...]
	OK
	If there is any error related to ME functionality: +CME ERROR: <errcode>
Write Command Query VTG sentence AT+QGPSGNMEA="VTG"	Response [+QGPSGNMEA: <VTG_sentence>] [...]
	OK
	If there is any error related to ME functionality: +CME ERROR: <errcode>
Write Command Query GLL sentence AT+QGPSGNMEA="GLL"	Response [+QGPSGNMEA: <GLL_sentence>] [...]
	OK

	If there is any error related to ME functionality: +CME ERROR: <errcode>
Maximum Response Time	300 ms
Characteristics	/

Parameter

<NMEA_type>	String type. NMEA sentence type. "GGA" GGA sentence "RMC" RMC sentence "GSV" GSV sentence "GSA" GSA sentence "VTG" VTG sentence "GLL" GLL sentence
<GGA_sentence>	String type. GGA sentences.
<RMC_sentence>	String type. RMC sentences.
<GSV_sentence>	String type. GSV sentences.
<GSA_sentence>	String type. GSA sentences.
<VTG_sentence>	String type. VTG sentences.
<GLL_sentence>	String type. GLL sentences.
<errcode>	Error codes. See Chapter 4 for details.

2.3.7. AT+QAGPS Enable/Disable AGPS

This command enables or disables AGPS feature of GNSS.

AT+QAGPS Enable/Disable AGPS	
Read Command AT+QAGPS?	Response +QAGPS: <enable> OK
Write Command AT+QAGPS=<enable>	Response OK If there is any error related to ME functionality: +CME ERROR: <errcode>
Maximum Response Time	300 ms
Characteristics	The command takes effect after the module is rebooted. The configuration is saved automatically.

Parameter

<enable> Integer type. Enable or disable AGPS feature of GNSS.

0 Disable

1 Enable

<errcode> Error codes. See **Chapter 4** for details.

3 Example

3.1. Turn on NMEA Port to Output NMEA Sentences


Configure the output port of NMEA sentences as UAB NMEA port through **AT+QGPSCFG="outport","usbnmea"**, as shown below:

```
AT+QGPSCFG="outport","usbnmea"          // Configure the output port of NMEA sentences as UAB
                                            // NMEA port.  
OK  
AT+QGPS=1                                //Open GNSS.  
OK
```


The enumeration and configuration of USB NMEA ports in Windows and Linux are described in detail as follows.

- Windows

Step 1: After USB is inserted, Quectel USB NMEA Port (COM43) appears in Windows Device Manager.



Step 2: Use the serial port tool to open COM43, and send **AT+QGPS=1** via USB AT port or the main serial port to turn on GNSS, then NMEA sentence is output by default.



- Linux

Step 1: After the USB is inserted into the host, execute **dmesg**. There are 4 serial devices, and **ttyUSB3** is USB NMEA port. *InterfaceNumber* of the two endpoints of NMEA both are 6.

```

[49011.062809] usb 1-1: New USB device found, idVendor=2c7c, idProduct=6002, bcdDevice= 3.18
[49011.062850] usb 1-1: New USB device strings: Mfr=1, Product=2, SerialNumber=3
[49011.062862] usb 1-1: Product: Android
[49011.062867] usb 1-1: Manufacturer: Android
[49011.062869] usb 1-1: SerialNumber: 0000
[49011.082443] cdc_ether 1-1:1.0 usb0: register 'cdc_ether' at usb-0000:02:03.0-1, CDC Ethernet Device, ae:0c:29:a3:9b:6d
[49011.093858] option 1-1:1.2: GSM modem (1-port) converter detected
[49011.094280] usb 1-1: GSM modem (1-port) converter now attached to ttyUSB0
[49011.096939] option 1-1:1.3: GSM modem (1-port) converter detected
[49011.101396] usb 1-1: GSM modem (1-port) converter now attached to ttyUSB1
[49011.103742] option 1-1:1.4: GSM modem (1-port) converter detected
[49011.104559] usb 1-1: GSM modem (1-port) converter now attached to ttyUSB2
[49011.107604] option 1-1:1.6: GSM modem (1-port) converter detected
[49011.108554] usb 1-1: GSM modem (1-port) converter now attached to ttyUSB3
[49011.258726] cdc_ether 1-1:1.0 enxae0c29a39b6d: renamed from usb0
[49011.623926] IPv6: ADDRCONF(NETDEV_CHANGE): enxae0c29a39b6d: link becomes ready

```

```

root@ubuntu:/home/evin/Desktop# cat /sys/bus/usb/devices/1-1:1.6/interface
Mobile NMEA Interface
root@ubuntu:/home/evin/Desktop# cat /sys/bus/usb/devices/1-1:1.6/bInterfaceNumber
06

```

Step 2: Use minicom to open *ttyUSB3*, and NMEA sentence is output.

```
root@ubuntu:/home/evin/Desktop# minicom -D /dev/ttyUSB3

Welcome to minicom 2.7.1

OPTIONS: I18n
Compiled on Dec 23 2019, 02:06:26.
Port /dev/ttyUSB3, 10:53:36

Press CTRL-A Z for help on special keys

$GNRMC,,V,,,,,,,,,N,V*37
$GNGGA,,,,,,0,00,99.99,,,,,*56
$GNGSA,A,1,,,,,,,,,,,99.99,99.99,99.99,1*33
$GNGSA,A,1,,,,,,,,,,,99.99,99.99,99.99,4*36
$GNGSA,A,1,,,,,,,,,,,99.99,99.99,99.99,3*31
$GPGSV,1,1,00,0*65
$GBGSV,1,1,00,0*77
$GAGSV,1,1,00,0*74
$GNVTG,,,,,,N*2E
$GNRMC,,V,,,,,,,,,N,V*37
$GNGGA,,,,,,0,00,99.99,,,,,*56
```

3.2. Turn on/off GNSS

Default parameters are used in this example to turn on GNSS. After turning on GNSS, GNSS can be turned off through **AT+QGPSEND**.

```
AT+QGPS=1          //Turn on GNSS.  
OK  
AT+QGPSLOC=0      //Obtain positioning information.  
+QGPSLOC: 063416.40,3143.2951N,11713.0655E,0.6,224.9,2,162.57,17.6,9.5,110620,07  
  
OK  
AT+QGPSEND        //Turn off GNSS.  
OK
```

3.3. Application of <NMEA_src>

When GNSS is turned on and <NMEA_src> is set to 1, NMEA sentences can be acquired directly through **AT+QGPSGNMEA**.

AT+QGPSCFG="nmeasrc",1	//Set <NMEA_src> to 1 to enable acquisition of NMEA sentences through AT+QGPSGNMEA .
OK	
AT+QGPSGNMEA="GGA"	//Obtain GGA sentence.
+QGPSGNMEA: \$GPGGA,103647.000,3150.721154,N,11711.925873,E,1,02,4.7,59.8,M,-2.0,M,*77	
OK	
AT+QGPSCFG="nmeasrc",0	//Set <NMEA_src> to 0 to disable acquisition of NMEA sentences through AT+QGPSGNMEA .
OK	
AT+QGPSGNMEA="GGA"	//Obtain GGA sentence.
+CME ERROR: 507	//Acquisition of NMEA sentences through AT+QGPSGNMEA was disabled, and thus GGA sentences cannot be obtained.

3.4. Application of AGPS Feature

AT+QAGPS=1 is executed to enable AGPS feature. Ephemeris data can be acquired automatically every time when the module is powered on and the GNSS is turned on under the premise that the network is normal to achieve a quick positioning.

AT+QAGPS=1	//Enable AGPS feature.
OK	
AT+QGPS=1	//Turn on GNSS.
OK	

4 Summary of Error Codes

The **<errcode>** indicates an error related to GNSS operation. The details about **<errcode>** are described in the following table.

Table 2: Summary of Error Codes

<errcode>	Meaning
501	Invalid parameter(S)
502	Operation not supported
503	GNSS subsystem busy
504	Session is ongoing
505	Session not active
506	Operation timeout
507	Function not enabled
508	Time information error
512	Validity time is out of range
513	Internal resource error
514	GNSS locked
515	End by E911
516	Not fixed now
517	CMUX port is not opened
549	Unknown error

5 Appendix References

Table 3: Terms and Abbreviations

Abbreviation	Description
AGPS	Assisted GPS (Global Positioning System)
BeiDou	BeiDou Navigation Satellite System
DOP	Dilution of Precision
Galileo	Galileo Satellite Navigation System
GGA	Global Positioning System Fix Data
GLONASS	Global Navigation Satellite System
GNSS	Global Navigation Satellite System
GPS	Global Positioning System
GSA	GPS DOP and Active Satellites
GSV	Satellites in View
ME	Mobile Equipment
MS	Mobile Station
NMEA	NMEA (National Marine Electronics Association) 0183 Interface Standard
NVRAM	Non-Volatile Random Access Memory
RAM	Random Access Memory
RMC	Recommended Minimum Specific GNSS Data
UART	Universal Asynchronous Receiver & Transmitter
USB	Universal Serial Bus
UTC	Universal Time Code

VTG

Course Over Ground and Ground Speed
