

EG800Q&EG91xQ Series

QuecCell Application Note

LTE Standard Module Series

Version: 1.2

Date: 2024-06-24

Status: Released



At Quectel, our aim is to provide timely and comprehensive services to our customers. If you require any assistance, please contact our headquarters:

Quectel Wireless Solutions Co., Ltd.

Building 5, Shanghai Business Park Phase III (Area B), No.1016 Tianlin Road, Minhang District, Shanghai 200233, China

Tel: +86 21 5108 6236

Email: info@quectel.com

Or our local offices. For more information, please visit:

<http://www.quectel.com/support/sales.htm>.

For technical support, or to report documentation errors, please visit:

<http://www.quectel.com/support/technical.htm>.

Or email us at: support@quectel.com.

Legal Notices

We offer information as a service to you. The provided information is based on your requirements and we make every effort to ensure its quality. You agree that you are responsible for using independent analysis and evaluation in designing intended products, and we provide reference designs for illustrative purposes only. Before using any hardware, software or service guided by this document, please read this notice carefully. Even though we employ commercially reasonable efforts to provide the best possible experience, you hereby acknowledge and agree that this document and related services hereunder are provided to you on an “as available” basis. We may revise or restate this document from time to time at our sole discretion without any prior notice to you.

Use and Disclosure Restrictions

License Agreements

Documents and information provided by us shall be kept confidential, unless specific permission is granted. They shall not be accessed or used for any purpose except as expressly provided herein.

Copyright

Our and third-party products hereunder may contain copyrighted material. Such copyrighted material shall not be copied, reproduced, distributed, merged, published, translated, or modified without prior written consent. We and the third party have exclusive rights over copyrighted material. No license shall be granted or conveyed under any patents, copyrights, trademarks, or service mark rights. To avoid ambiguities, purchasing in any form cannot be deemed as granting a license other than the normal non-exclusive, royalty-free license to use the material. We reserve the right to take legal action for noncompliance with abovementioned requirements, unauthorized use, or other illegal or malicious use of the material.

Trademarks

Except as otherwise set forth herein, nothing in this document shall be construed as conferring any rights to use any trademark, trade name or name, abbreviation, or counterfeit product thereof owned by Quectel or any third party in advertising, publicity, or other aspects.

Third-Party Rights

This document may refer to hardware, software and/or documentation owned by one or more third parties ("third-party materials"). Use of such third-party materials shall be governed by all restrictions and obligations applicable thereto.

We make no warranty or representation, either express or implied, regarding the third-party materials, including but not limited to any implied or statutory, warranties of merchantability or fitness for a particular purpose, quiet enjoyment, system integration, information accuracy, and non-infringement of any third-party intellectual property rights with regard to the licensed technology or use thereof. Nothing herein constitutes a representation or warranty by us to either develop, enhance, modify, distribute, market, sell, offer for sale, or otherwise maintain production of any our products or any other hardware, software, device, tool, information, or product. We moreover disclaim any and all warranties arising from the course of dealing or usage of trade.

Privacy Policy

To implement module functionality, certain device data are uploaded to Quectel's or third-party's servers, including carriers, chipset suppliers or customer-designated servers. Quectel, strictly abiding by the relevant laws and regulations, shall retain, use, disclose or otherwise process relevant data for the purpose of performing the service only or as permitted by applicable laws. Before data interaction with third parties, please be informed of their privacy and data security policy.

Disclaimer

- a) We acknowledge no liability for any injury or damage arising from the reliance upon the information.
- b) We shall bear no liability resulting from any inaccuracies or omissions, or from the use of the information contained herein.
- c) While we have made every effort to ensure that the functions and features under development are free from errors, it is possible that they could contain errors, inaccuracies, and omissions. Unless otherwise provided by valid agreement, we make no warranties of any kind, either implied or express, and exclude all liability for any loss or damage suffered in connection with the use of features and functions under development, to the maximum extent permitted by law, regardless of whether such loss or damage may have been foreseeable.
- d) We are not responsible for the accessibility, safety, accuracy, availability, legality, or completeness of information, advertising, commercial offers, products, services, and materials on third-party websites and third-party resources.

Copyright © Quectel Wireless Solutions Co., Ltd. 2024. All rights reserved.

About the Document

Revision History

Version	Date	Author	Description
-	2023-04-13	Alwyn YE	Creation of the document
1.0	2023-05-06	Alwyn YE	First official release
1.1	2023-08-25	Alwyn YE	Updated the applicable modules: <ul style="list-style-type: none"> Added EG916Q-GL. Updated EG800Q-EU to EG800Q series.
1.2	2024-06-24	Bronson ZHAN	<ol style="list-style-type: none"> Updated EG915Q-NA to EG915Q series. Updated the return value of AT+QENG="neighbourcell" (Chapter 2.3). Updated maximum response time of AT+QCELL (Chapter 2.4).

Contents

About the Document.....	3
Contents	4
Table Index.....	5
1 Introduction	6
2 Description of AT Commands	7
2.1. AT Command Introduction.....	7
2.1.1. Definitions.....	7
2.1.2. AT Command Syntax.....	7
2.2. Declaration of AT Command Examples	8
2.3. AT+QENG Get Information of Primary Serving Cell and Neighbour Cells	8
2.4. AT+QCELL Get Information of Serving Cell and Neighbour Cells	10
3 Appendix References	13

Table Index

Table 1: Types of AT Commands	7
Table 2: Terms and Abbreviations	13

1 Introduction

This document introduces AT commands related to QuecCell on Quectel EG800Q series, EG915Q series and EG916Q-GL modules.

QuecCell is a featured function embedded Quectel modules. It can be used to scan the detailed information of base stations.

2 Description of AT Commands

2.1. AT Command Introduction

2.1.1. Definitions

- **<CR>** Carriage return character.
- **<LF>** Line feed character.
- **<...>** Parameter name. Angle brackets do not appear on command line.
- **[...]** Optional parameter of a command or an optional part of TA information response. Square brackets do not appear on the command line. When an optional parameter is not given in a command, the new value equals its previous value or the default settings, unless otherwise specified.
- **Underline** Default setting of a parameter.

2.1.2. AT Command Syntax

All command lines must start with **AT** or **at** and end with **<CR>**. Information responses and result codes always start and end with a carriage return character and a line feed character: **<CR><LF><response><CR><LF>**. In tables presenting commands and responses throughout this document, only the commands and responses are presented, and **<CR>** and **<LF>** are deliberately omitted.

Table 1: Types of AT Commands

Command Type	Syntax	Description
Test Command	AT+<cmd>=?	Test the existence of the corresponding command and return information about the type, value, or range of its parameter.
Read Command	AT+<cmd>?	Check the current parameter value of the corresponding command.
Write Command	AT+<cmd>=<p1>[,<p2>[,<p3>[...]]]	Set user-definable parameter value.
Execution Command	AT+<cmd>	Return a specific information parameter or perform a specific action.

2.2. Declaration of AT Command Examples

The AT command examples in this document are provided to help you familiarize with AT commands and learn how to use them. The examples, however, should not be taken as Quectel's recommendation or suggestions about how you should design a program flow or what status you should set the module into. Sometimes multiple examples may be provided for one AT command. However, this does not mean that there exists a correlation among these examples and that they should be executed in a given sequence.

2.3. AT+QENG Get Information of Primary Serving Cell and Neighbour Cells

This command gets the information of the primary serving cell and neighbour cells.

AT+QENG Get Information of Primary Serving Cell and Neighbour Cells	
Test Command AT+QENG=?	Response +QENG: (list of supported <cell_type>s) OK
Write Command AT+QENG="servingcell"	Response +QENG: "servingcell",<state>,"LTE",<is_tdd>,<MCC>,<MNC>,<cellID>,<PCI>,<EARFCN>,<freq_band_ind>,<UL_bandwidth>,<DL_bandwidth>,<TAC>,<RSRP>,<RSRQ>,<RSSI>,<SINR>,<srxlev> OK
Write Command AT+QENG="neighbourcell"	Response [+QENG: "neighbourcell intra","LTE",<EARFCN>,<PCI>,<RSRP>,<RSRQ>,-,-,-,-,- [...] [+QENG: "neighbourcell inter","LTE",<EARFCN>,<PCI>,<RSRP>,<RSRQ>,-,-,-,-,- [...] OK
Maximum Response Time	300 ms
Characteristics	/

Parameter

<cell_type>	String type. Information of different cells. "servingcell" Information of 4G serving cells "neighbourcell" Information of 4G neighbour cells
<state>	String type. UE state. "SEARCH" UE is searching but could not (yet) find a suitable 4G cell "LIMSRV" UE is camping on a cell but has not registered on the network "NOCONN" UE has camped on a cell and registered on the network, and it is in idle state "CONNECT" UE has camped on a cell and registered on the network, and a call is in progress
<is_tdd>	String type. Communication mode. "TDD" Time division duplex mode "FDD" Frequency division duplex mode
<MCC>	Integer type. Mobile country code (first part of the PLMN code).
<MNC>	Integer type. Mobile network code (second part of the PLMN code).
<cellID>	Hexadecimal format. Cell ID. Range: 0–0xFFFFFFFF.
<PCI>	Integer type. Physical cell identity. Range: 0–503.
<EARFCN>	Integer type. E-UTRA absolute radio frequency channel number.
<freq_band_ind>	Integer type. E-UTRA frequency band. (See 3GPP 36.101).
<UL_bandwidth>	Integer type. Uplink bandwidth. 0 1.4 MHz 1 3 MHz 2 5 MHz 3 10 MHz 4 15 MHz 5 20 MHz
<DL_bandwidth>	Integer type. Downlink bandwidth. 0 1.4 MHz 1 3 MHz 2 5 MHz 3 10 MHz 4 15 MHz 5 20 MHz
<TAC>	Hexadecimal format. Tracking area code. Range: 0–0xFFFFFFFF. (See 3GPP 23.003 subclause 19.4.2.3).
<RSRP>	Integer type. Reference signal received power. Range: -156 to -44. Unit: dBm. (See 3GPP 36.214 subclause 5.1.1).
<RSRQ>	Integer type. Reference signal received quality. Range: -34 to 2.5. Unit: dB. (See 3GPP 36.214 subclause 5.1.3).
<RSSI>	Integer type. Received signal strength indication. Range: -120 to -25. Unit: dBm.

<SINR>	Integer type. Signal to interference plus noise ratio. Range: -20 to 40. Unit: dB.
<srxlev>	Integer type. Cell selection Rx level value. Unit: dB. (See 3GPP 25.304/3GPP 36.304).

NOTE

- After executing **AT+QENG="neighbourcell"**, if intra-frequency neighbour cell is found, **+QENG: "neighbourcell intra","LTE",<EARFCN>,<PCI>,<RSRP>,<RSRQ>,-,-,-,-,-** is returned; if inter-frequency neighbour cell is found, **+QENG: "neighbourcell inter","LTE",<EARFCN>,<PCI>,<RSRP>,<RSRQ>,-,-,-,-,-** is returned. If intra-frequency neighbour cell is found, the information of intra-frequency neighbour cell is returned first; if intra-frequency neighbour cell is not found, only the information of inter-frequency neighbour cell is returned.
- It indicates that the parameter is invalid under current conditions when "-" or - is returned.

Example

AT+QENG="servingcell"

+QENG: "servingcell","SEARCH"

OK

AT+QENG="servingcell"

+QENG:"servingcell","NOCONN","LTE","FDD",460,11,B57DE09,352,100,1,5,5,B504,-85,-8,-70,13,37

OK

AT+QENG="neighbourcell"

+QENG: "neighbourcell intra","LTE",100,353,-106,-20,-,-,-,-,-

+QENG: "neighbourcell intra","LTE",100,210,-106,-20,-,-,-,-,-

+QENG: "neighbourcell inter","LTE",1850,63,-88,-19,-,-,-,-,-

+QENG: "neighbourcell inter","LTE",1850,362,-96,-20,-,-,-,-,-

OK

2.4. AT+QCELL Get Information of Serving Cell and Neighbour Cells

This command gets the information of the serving cell and neighbour cells.

AT+QCELL Get Information of Serving Cell and Neighbour Cells

Test Command

Response

AT+QCELL=?	OK
Read Command AT+QCELL?	Response +QCELL: "servingcell","LTE",<MCC>,<MNC>,<TAC>,<cellID>,<PCI>,<RX_lev> [+QCELL: "neighbourcell intra","LTE",<MCC>,<MNC>,<TAC>,<cellID>,<PCI>,<RX_lev> [...]] [+QCELL: "neighbourcell inter","LTE",<MCC>,<MNC>,<TAC>,<cellID>,<PCI>,<RX_lev> [...]] OK
Maximum Response Time	300 ms
Characteristics	/

Parameter

<MCC>	Integer type. Mobile country code (the first part of the PLMN code).
<MNC>	Integer type. Mobile network code (the second part of the PLMN code).
<TAC>	Hexadecimal format. Tracking area code. Range: 0–0xFFFFFFFF. (See 3GPP 23.003 Section 19.4.2.3).
<cellID>	Hexadecimal format. Cell ID. Range: 0–0xFFFFFFFF.
<PCI>	Integer type. Physical cell identity. Range: 0–503.
<RX_lev>	Integer type. Rx level in the cell. Range: 0–63. Unit: dB. (See 3GPP 25.304).

NOTE

1. This command can only be executed when the (U)SIM card is not inserted or when the module is in the idle state with the (U)SIM card inserted; it is recommended to use the command when the (U)SIM card is not inserted.
2. After executing **AT+QCELL?**, if intra-frequency neighbour cell is found, **+QCELL: "neighbourcell intra","LTE",<MCC>,<MNC>,<TAC>,<cellID>,<PCI>,<RX_lev>** is returned; if inter-frequency neighbour cell is found, **+QCELL: "neighbourcell inter","LTE",<MCC>,<MNC>,<TAC>,<cellID>,<PCI>,<RX_lev>** is returned. If intra-frequency neighbour cell is found, the information of intra-frequency neighbour cell is returned first; if intra-frequency neighbour cell is not found, only the information of inter-frequency neighbour cell is returned.

Example

```
AT+QCELL?           // Get the information of serving cell and neighbour cells.
+QCELL: "servingcell","LTE",460,00,550b,d6b5c0,123,36
```

+QCELL: "neighbourcell inter","LTE",460,00,550b,5e05e2a,20,12

+QCELL: "neighbourcell inter","LTE",460,00,550b,5c4ef29,121,25

OK

3 Appendix References

Table 2: Terms and Abbreviations

Abbreviation	Description
3GPP	The 3rd Generation Partnership Project
DL	Downlink
EARFCN	E-UTRA Absolute Radio Frequency Channel Number
E-UTRA	Evolved-Universal Terrestrial Radio Access
FDD	Frequency Division Duplex
LTE	Long Term Evolution
MCC	Mobile Country Code
MNC	Mobile Network Code
PCI	Physical Cell Identity
PLMN	Public Land Mobile Network
RSRP	Reference Signal Received Power
RSRQ	Reference Signal Received Quality
RSSI	Received Signal Strength Indicator
SINR	Signal to Interference Plus Noise Ratio
TA	Terminal Adapter
TAC	Tracking Area Code
TDD	Time Division Duplex
UE	User Equipment
UL	Uplink
UTRA	UMTS Terrestrial Radio Access